

Innovation for Sustainable Production – i-SUP 2008
Congrescentrum Oud Sint-Jan, Brugge
21. – 24. April 2008

MANUFACTURING OF MICROPOROUS CERAMIC MEMBRANES FOR ENVIRONMENTAL APPLICATIONS

I. CO₂-free power plants
II. Fuel cells

Tim Van Gestel, Wilhelm A. Meulenberg, Hans Peter Buchkremer

Forschungszentrum Jülich GmbH
Institute of Energy Research – Materials Synthesis and Processing (IEF-1)
D-52425 Jülich

Membrane research topics in IEF-1


Focus on energy-related applications :

- 1 Development of porous and dense membranes for application in CO₂-free power plants**
 - dense membranes for O₂/N₂ separation
 - microporous membranes for CO₂/H₂ separation ✓

- 2 Development of porous and dense membranes for application in advanced Solid Oxide Fuel Cells (SOFC's)**
 - porous anode and cathode layers
 - dense electrolyte membrane ✓


Microporous membranes for CO₂ separation

Example: Metal-supported Membranes for H₂/CO₂-Separation



Microporous membranes for CO₂ separation

Example: Multilayer-Membrane on ceramic ZrO₂ substrate



Sol-Gel Method:

Nano-Particle sol
Particle size ~ 6 nm

Sol-Gel Method:

Colloidal Particle Sol
Particle size ~ 30 nm

Suspension Method:

Particle size ~ 350 nm
- Vacuum slip-casting
- Dip-coating
- Screen-printing

Powder Method:

Warm-pressing

Microporous membranes for CO₂ separation

Substrate preparation – Warmpressing


Warmpressing 8Y₂O₃-ZrO₂ Substrate + Sintering (1200 °C)







Particle size: ~ 3 - 5 µm
Average Pore size: ~ 1 µm

Large-scale Support: Preparation with Standard IEF-1 Technology for Solid Oxide Fuel Cells SOFC's (25 x 25 cm)





Lab-scale Support for R & D: Polishing with diamant particles for improving Surface roughness (4 x 4 cm)







Macroporous Interlayer - Suspension coating




Mesoporous interlayer - Sol-gel coating




Microporous toplayer - Sol-Gel Coating




Microporous top layer - Sol-Gel Coating



Microporous toplayer - Sol-Gel Coating



Overview subsequent membrane coating steps




Membrane research topics in IEF-1

Focus on energy-related applications :

- 1 Development of porous and dense membranes for application in CO₂-free power plants**
 - dense membranes for O₂/N₂ separation
 - microporous membranes for CO₂/H₂ separation ✓


- 2 Development of porous and dense membranes for application in advanced Solid Oxide Fuel Cells (SOFC's)**
 - porous anode and cathode layers
 - dense electrolyte membrane ✓

Standard FZ-Jülich SOFC



- Planar configuration ($\rightarrow 20 \text{ cm} \times 20 \text{ cm}$)
- Anode supported concept with thin-film electrolyte
- $I = \sim 1.5 \text{ A/cm}^2$ at 800°C and 0.7 V (single cell); $\sim 1.1 \text{ A/cm}^2$ (stack)
- Demonstrated 60-cell stack with 13 kW; in progress 20 kW system

Novel membranes for advanced SOFC's



dense $8\text{Y}_2\text{O}_3\text{-ZrO}_2$ electrolyte membrane
on porous $\text{NiO}/8\text{Y}_2\text{O}_3\text{-ZrO}_2$ substrate


Conventional preparation method:

- (1) Deposition of macroporous membrane starting from ZrO_2 powder suspension
- (2) Sintering of macroporous membrane at high temperature (1400°C , 5h)


Proposed alternative preparation method:

- (1) Deposition of membrane starting from ZrO_2 nano-particles
(e.g. Coating with ultra-fine suspension or sol)
- (2) Sintering at lower temperature (objective $< 1100^\circ\text{C}$)
- (3) Possibility to apply steel substrate, reduction of production cost


Novel membranes for advanced SOFC's







Novel membranes for advanced SOFC's



Novel membranes for advanced SOFC's




Novel membranes for advanced SOFC's




Novel membranes for advanced SOFC's

Coating with ultra-fine suspension
(+ firing 1300°C)




Coating with ultra-fine suspension and
sol (+ firing 1300°C)




Surface $8\text{Y}_2\text{O}_3\text{-ZrO}_2$ layer after firing at 1300°C

Standard
1400°C




Surface $8\text{Y}_2\text{O}_3\text{-ZrO}_2$ layer after firing at 1300°C


Standard
1400°C




Novel membranes for advanced SOFC's




Novel membranes for advanced SOFC's



Novel membranes for advanced SOFC's




Novel membranes for advanced SOFC's




Novel membranes for advanced SOFC´s

Surface $8\text{Y}_2\text{O}_3\text{-ZrO}_2/\text{NiO}$ anode layer (on standard SOFC substrate)



Novel membranes for advanced SOFC´s

Surface $8\text{Y}_2\text{O}_3\text{-ZrO}_2$ porous membrane after firing at 600°C




FZJ : IEF 2008

EHT = 15.00 kV Detector = InLens WD = 7 mm

2μm

Novel membranes for advanced SOFC´s

Surface $8\text{Y}_2\text{O}_3\text{-ZrO}_2$ membrane after firing at 1200°C




FZJ : IEF 2008

EHT = 15.00 kV Detector = InLens WD = 8 mm

2µm

Novel membranes for advanced SOFC's

Detail 8Y₂O₃-ZrO₂ membrane after firing at 1200°C



FZJ : IEF 2008

EHT = 15.00 kV Detector = InLens WD = 8 mm

200nm

State of the art - Conclusion

- ☞ Current gas separation membranes are made of SiO_2 materials, having an insufficient (hydro)thermal stability for application in power plant streams
- ☞ Current solid oxide fuel cells are made by unwanted high-temperature sinter treatments

In this work :

- ◆ Manufacturing of novel nano-structured ZrO_2 membranes
- ◆ Widely accepted material for long-term operation in gas separation
- ◆ Densification material at a lower temperature for SOFC manufacturing


In progress :

- ◆ Optimization of the membrane pore size (target: high H_2/CO_2 selectivity)
- ◆ Manufacturing SOFC's for current density characterization

Acknowledgement :

Funding by Helmholtz Association
of German Research Centers

Helmholtz Alliance MEM-BRAIN



SEM images made by
Dr. Doris Sebold
IEF-1