

# Zeolitic-nanoblock membranes for gas separation

K. Wyns, A. Buekenhoudt (VITO)

J. Martens, P. Jacobs (KULeuven)

J. Denaeyer, G. Baron (VUBrussels)

D. Liang, G. Van Tendeloo (UAntwerpen)

SBO Project funded by IWT



# Membrane synthesis

- Standard zeolite membranes :  
hydrothermal synthesis  
with in-situ growth, or seeding and secondary growth
- Our method :  
stacking from nano zeolite-precursors  
from clear solution



# Nano zeolite-precursors

R&D in different groups :

[Tsapatsis], [Schoeman], [Corma], [Martens] :


- In clear solution
- With specific ratio of TPA/SiO<sub>2</sub> in solution
- Existence of precursor nanoparticles of a few nm  
by SAXS, DLS, TEM, HRTEM, AFM
- Contribute to crystal growth by oriented aggregation
- Structure of precursors in debate :  
amorphous or crystalline ?



# Nano zeolite-precursors

- TEM on silicalite clear solution, aged at RT (UAntwerpen)

D. Liang, Van Tendeloo et al, submitted J. Phys. Chem. C.





Black bar = 10 nm



# Nano zeolite-precursors

- TEM on silicalite clear solution, aged at RT (UAntwerpen)  
D. Liang, Van Tendeloo et al, submitted J. Phys. Chem. C.




**Crystalline nanoblocks !**

# Zeolitic nanoblocks

View of K.U.Leuven

Kirschock et al., *Angewandte Chemie*, 40, 2637; 2001

- Basic unit = rectangular nanoblock
- Nanoblocks have zeolite-like properties = zeolitic
- Nanoblocks are  $4 \times 4 \times 1.3 \text{ nm}^3$
- Can be used as building units





- 9 short zig/zag channels along a-axis
- 3 long, straight channels along b-axis
- channels 0.5 nm wide



# Zeogrid powder


Kremer et al., Adv. Funct. Mater., 12, 286, 2002 (KULeuven)

- Nanoblocks can be stacked in a layered way with the use of appropriate surfactants
- Leads to micrometer large grains called zeogrid
- Zeogrid calcined has dual porosity : micropores + interblock voids




# Zeogrid powder

N<sub>2</sub> adsorption : **bi-porosity**  
micropores + supermicropores



Low-angle XRD : **no zeolite**  
layering with repetition of 3 nm






sample	V(micro) cc/g	V(big micro) cc/g	S(tot) m <sup>2</sup> /g
CTAB	0.14	0.53	1243
DTAB	0.14	0.40	948





# Zeotile powder

Kremer et al., Adv. Mater., 20, 1705, 2003 (KULeuven)



Different way of stacking  
with the aid of surfactants :



Hexagonal stacking  
of double nanoslab units





One dimensional channels  
of ~3.5 nm

White bar = 10 nm

Images: UAntwerpen

# Zeolitic-nanoblock membranes

- Zeogrid on porous support :  
dipping in solution of nanoblocks + surfactants




Calcination = removal of surfactant/TPA, no crystal growth

# Zeolitic-nanoblock membranes

Possible advantages :

- thin membranes  $< 100$  nm : high flux, crack free
- bi-porosity : extra high flux
- defect-free + entrance via nanoblock : high selectivity





**Goal : Potential of these membranes ?**




# Preliminary tests : Zeolitic-nanoblock film on Si wafer

N<sub>2</sub> adsorption :



Low angle XRD :



**Zeolitic film**  
~  
**zeogrid powder**



# Zeolitic-nanoblock membranes

Zeogrid layer on porous support :

- flat and tubular
- $\alpha$ -Al<sub>2</sub>O<sub>3</sub>/TiO<sub>2</sub> (50-100 nm) + TiO<sub>2</sub> (3 nm)

Quality test :

- NF with small PEG's in water (200, 600, 1500 Dalton)
- defect-free membrane has MWCO < 200 D + low flux
- R(1500D) measures defects and supermicropores > 1.5 nm



Current quality on tubes :

- MWCO : 500 à 1000 D, R(1500D) > 95%



# FESEM characterisation

on a fracture plane, 30° tilt



# TEM characterisation


100nm

- disordered pore structure of few nm
- no ED = no regular stacking




entrance through  
supermicropores

Measurement : G. Van Tendeloo, D. Liang, UAntwerpen




# Adsorption measurements on zeotile/zeogrid powder at RT

VUB: CO<sub>2</sub> adsorption





# Adsorption measurements on zeogrid powder at RT



powder interesting as CO<sub>2</sub> adsorbent  
membranes interesting for CO<sub>2</sub> gas separation

Measurements: VUB



# Single gas separation measurements

gas	Permeability at RT (l/hm <sup>2</sup> .bar)	Permeability at 200°C (l/hm <sup>2</sup> .bar)
N <sub>2</sub>	M1 : 1290 M2 : 4500	M1 : 1800 M2 : - -
SF <sub>6</sub>	M1 : 960 M2 : 1950	M1 : - - M2 : - -
H <sub>2</sub>	M1 : 4200 M2 : 11700	M1 : 5850 M2 : - -
CO <sub>2</sub>	M1 : 1500 M2 : 3300	M1 : 2100 M2 : - -

- permeabilities independant of TMP
  - ~ Knudsen permselectivities
  - permeabilities increase with T
- 1000 l/hm<sup>2</sup>bar = 1,24 · 10<sup>-7</sup> mol/m<sup>2</sup>sPa



# Double gas separation measurements

gas	Selectivity	Permeability at RT (l/hm <sup>2</sup> .bar)
N <sub>2</sub> /CO <sub>2</sub> 88/12	0.6 (1.25)	3000
H <sub>2</sub> /CO <sub>2</sub> 40/60	1.7 (4.7)	9000

Permeate side : P = 1 atm

TMP = 1 or 2 bar



CO<sub>2</sub> adsorption  
High fluxes  
Low selectivities



# Conclusions for zeolitic membranes

- SEM/TEM show nice membranes with clear bi-porosity
- Current quality : 500 à 1000 D,  $R(1500D) > 95\%$
- Adsorption on powder shows extra high CO<sub>2</sub> capacity at high pressures : clear potential
- First gas separation results :
  - Single gas separation shows
    - ~ Knudsen behavior, high fluxes increasing with T
  - Double gas separation at low pressure shows CO<sub>2</sub> adsorption, high fluxes
- Gas separation measurements at high pressure planned

